

HOLDER for LED HEADLIGHT

ready for BMW R1200GS 2008 - 2013 K25



Remove the seat, you have a charging socket on the left Side.

Remove the insulation and solder \oplus to the red/green and

\ominus to the brown wire.

Fix the two clips to the panels by a bracket with a hole in the frame , below the dashboard.

we attached is some fotos for help to instalation

regards,Oldtimers TEAM

